


DRY BAG 3-ROLL CLOSURE INSTRUCTIONS




1 STUFF IT



1. The first step with any dry bag is loading your gear! To get a proper closure for maximum protection, do not load the bag beyond the dashed fill line.

Getting the perfect splashproof seal requires rolling the top edge of the bag downward three times. so make sure to leave room.


2 ROLL IT



2. Next, fold the bag once at the base of the buckles (see inset image above), and squeeze down to purge excess air from the bag.

Maintaining the single fold, tightly roll a minimum of three additional times for a secure seal.

3 BUCKLE IT



3. Once you've achieved at least three tight rolls, close the quick-release buckles together, and you're ready to go!

Warranty: Seattle Sports products are guaranteed for workmanship and materials for one year. Should this product fail during that period, Seattle Sports will repair or replace the product at their discretion (after product inspection). Please email Seattle Sports Company for a return authorization at contact@seattlesportsco.com. This warranty is void with commercial use and in no event should Seattle Sports Company be liable for incidental or consequential damages. When closed properly, Seattle Sports dry bags protect against rain, splash, spray, and short-term submersion. Roll closure bags are not designed for long-term submersion. Not intended for storage of optical, photographic or electrical equipment. © 2014 Seattle Sports Company.



CHECK OUT MORE GEAR AT
[YouTube.com/SeattleSportsCoTV](https://www.youtube.com/SeattleSportsCoTV)

SEATTLE SPORTS CO
3217 W. Smith St.
Seattle, WA 98199
seattlesportsco.com

© 2014 Seattle Sports Company.